
UNFOLD

1 | UNFOLD Remove the V tent from the carry bag and unfold the frame.

2 | POSITIONING Make sure the canopy is above and the legs are below



3 | TIGHTEN VALVES Each leg have 2 inflate / deflate valve and 1 overpressure valve. Tighten the valves.









INFLATING


4 | INFLATING Insert the electric pump into the opened inflate / deflate valve and inflating the three legs separately

ABOUT THE PRESSURE

Inflate untill the tube feels very solid (3PSI/0.2BAR). The remaining air will escape through the overpressure valve.














POSITIONING

5 | POSITIONING LEGS Drive 6 stakes into the ground at an angle of 40 degrees . When you cannot use stakes on solid ground , you can buckle 3 water barrels to the 3 legs .





Sand or snow





Solid Ground












REPLACE THE CANOPY

6 | REMOVE THE OLD CANOPY Find the zipper head and remove the canopy in the direction of the arrow 7 | INSTALL THE NEW CANOPY, Find the zipper head and install the canopy in the direction of the arrow










DEFLATE

FOLDING & STORAGE

8 | DEFLATE


Deflate V tent by opening the 6 inflation valves. Do not remove the overpressure valves





9 | FOLD


10 | STORAGE


Do not storage the V tent when it's wet. Hang both frame and cloths in a dry environment.













DO'S AND DONT'S

cleaning

when it's wet



Do not use sharp objects

Do not use chemicals for

Do not use near an open

fire or heated objects

Do not store the V tent



Can be used till 6 bft.





Pressure (3PSI/0.2 BAR)



Anchor with stakes on soft ground



Anchor with water barrels on hard ground

NEVER LEAVE THE V TENT UNATTENDED AND TAKE CARE OF YOUR **BELONGINGS**

AFTER USE OF THE V TENT ONE STORE IT IN A DRY PLACE Never store a wet tent. Hang out all the canopy and the leg frame in a dry


and warm place.




Only use water with a soft handbrush and a wet cloth to clean the tent. Do not use any cleaning products.

PARTS

Canopy



Leg frame(cover+TPU bladder) 1x



Rope



TPU repair 2x



Sand bag 3x



Inflate/deflate valves 6x+2 spare valves



Overpressure valves 3x+1 spare valves



Stakes 6x

