

Straighten and connect all bungeed poles.



Organize all remaining poles by their numerical order & connect accordingly. Insert any remaining reinforcement poles.



Lift the frame and connect the footplates onto the frame.



Put on your fabric gloves and slide the printed graphic over the frame.

4




Zip up to close the cover.

## Tower Instructions Note: The push buttons on the Tower and Arch footplates must face backwards.



Repeat Steps 1-2 in general instructions.



Screw on the stabilizing tubes to connect the two sides of the frame together.



Put on your fabric gloves, then slide the graphics over the frame. Zip up halfway.



Connect the frame to its corresponding foot plates by screwing through holes in the fabric and securing with nuts. Finish zipping up the fabric.



Screw on clamps to the tower through holes in the fabric and then snap the arch into place.

## Case-2-Counter



Insert all four poles into the bottom case lid.



Connect the crossbars to the four poles by snapping them together.



Then, insert the top case into the four poles.



Pull the printed graphic over the frame. Then, buckle the two straps on the top & bottom.



Place top lid to cover the storage area and you're all set.

## Light



Attach metal clamp on top of wall/banner and tighten. Then, slide light onto clamp.



Ensure the light is switched off before attaching cord and plugging into outlet.



Locate the fabric holes and screw in the TV mount.




Screw mount base into the arch frame. Then, screw the mount arms onto the back of your TV.



Secure your TV to the mount by hooking the arms onto mount, and tightening screws

## TV Mount \*Max TV weight: 50 lbs. Max TV size: 42"



r**≻**⊡ 27 ••

15 16

Front